EXHIBIT P THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C R9-14-404(A)

ARIZONA DEPARTMENT OF HEALTH SERVICES

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 5000*

STANDARD CALIBRATION CHECK PROCEDURE

Agency		Date 2-13- 7002 Time 2048
		Serial # 66 - 004416 Location 6PD
QA Spe	Clan	(Print Name)
(M)	1.	Pour a standard alcohol solution of known value into a clean dry simulator jar and assemble the simulator. Insure that a tight seal has been made. Standard value: 0. O AC
(\mathcal{W})	2.	Turn on the simulator and allow the temperature to reach 34°C±.2°C.
(\mathbf{m})	3.	Set Intoxilyzer mode selection in the ACA mode by switching mode selection switch #9 on or selecting "C" on keyboard menu.
(\mathbf{p})	4.	Attach simulator to the simulator entrance port on the Intoxilyzer.
(Ŭ)	5.	Intoxilyzer 5000 display reads "READY TO START" or "PUSH BUTTON".
(\mathbf{U})	6.	Push Start Test button or press enter on keyboard.
(L)	7.	Insert card in response to display.
(U)		Air blank completed.
(سلن)	9.	Calibration check completed. Test results 0/0/ AC
	10.	Air blank completed.
(\mathbf{W})	11.	When display reads Test Complete remove evidence card. Attach the card to the completed checklist.
U)	12.	Return mode selection switch #9 to off position after all calibration checks are complete or type Q and
	ente	er on keyboard.
SIGNA	TUR	

*WITH OR WITHOUT VAPOR RECIRCULATION AND WITH OR WITHOUT KEYBOARD

DHS/DSLS/Form C116 (Rev. 7-93)

GOODYEAR POLICE DEPT. INTOXILYZER - ALCOHOL ANALYZER AZ MODEL 5000 SN 66-004416 02/23/2002 20:49 COPY NUMBER 1 OF 2 OFFICER BADGE=0000974 N.C.I.C NO.=AZ0071500 TEST BRAC VALUE TIME AIR BLANK .000 20:48 CAL, CHECK .101 20:49 AIR BLANK .000 20:49 OPERATOR: ADDITIONAL INFORMATION: _ ACS LOT

INTOXILYZER - ALCOHOL ANALYZER
AZ MODEL 5000 SN 66-004416
02/23/2002 20:51
COPY NUMBER 1 OF 1

OFFICER BADGE=G000974
N.C.I.C NO.=AZ0071500

DVM TEST

OPERATOR:
ADDITIONAL INFORMATION:
-3/e\

GOODYEAR POLICE DEPT.

GOODYEAR POLICE DEPT.
INTOXILYZER - ALCOHOL ANALYZER
AZ MODEL 5000 SN 66-004415
02/23/2002
COPY NUMBER 1 OF 1

20:52

OF F	Y	CER	BAD)GE	em (")	$\bigcirc\bigcirc$	09	7	ı::¦
N.C		I.C	NO.	, == A	ZO	07	15	Ö	0

DISPLAY TEST

OPERATOR:
ADDITIONAL INFORMATION:

GOODYEAR POLICE DEPT.
INTOXILYZER - ALCOHOL ANALYZER
AZ MODEL 5000 SN 66-004416
02/23/2002
COPY NUMBER 1 OF 1

20:53

OFFICER BADGE=0000974 N.C.I.C NO.=AZ0071500

TIME, DATE, LOC SET

OPERATOR:	
ADDITIONAL	. INFORMATION:

VERSION E 773.23 TIME 20:53

OFFICER BADGE=0000974 N.C.I.C NO.=AZ0071500
ABCDEFGHIJKLMNOPQRSTUVWXYZ0123456789'@#\$
OPERATOR:
ADDITIONAL INFORMATION:

SN 66-004416 VERSION E 773.23 DATE 02/23/2002 TIME 20:56 COPY NUMBER 1 OF 2

INVALID TEST

SUB NAME=TEST.SQAP-PB, SUB DOB =02/23/30 SUB SEX =MALE WEIGHT =001 OFFICER =WILL, W, C OFFICER BADGE=0000974 N.C.I.C NO.=AZ0071500

PRESSED START TEST AT IMPROPER TIME

OPERATOR:		William to the state of the sta
ADDITIONAL	. INFORMATION:	
71 1. 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		

GOODYEAR FOLICE DEPT.
INTOXILYZER - ALCOHOL ANALYZER
AZ MODEL 5000 SN 66-004416
02/23/2002 20:56
COPY NUMBER 1 OF 2

SUB NAME=TEST,SQAP-AF.
SUB DOB =02/23/30
SUB SEX =MALE WEIGHT =001
OFFICER =WILL,W,C
OFFICER BADGE=0000974
N.C.I.C NO.=AZ0071500

TEST BRAC VALUE TIME
AIR BLANK .000 20:55
SUBJECT TEST .000 20:55
AIR BLANK .000 20:55
OPERATOR:
ADDITIONAL INFORMATION:

VERSION E 773.23 TIME 20:58

INVALID TEST ,

OPERATOR:		
ADDITIONAL	INFORMATION:	
ACCIDENTACE	HIT START	אפדר שעדרים

SAMPLE INTRODUCED

VERSION E 773.23 TIME 20:59

INVALID TEST

SUB NAME=TEST.SQAF-BWT,
SUB DOB =02/23/30
SUB SEX =MALE WEIGHT =001
OFFICER =WILL,W.C
OFFICER BADGE=0000974
N.C.I.C NO.=AZ0071500

AT IMPROPER TIME.

OPERATOR:

ADDITIONAL INFORMATION:

INTOXILYZER - ALCOHOL ANALYZER AZ MODEL 5000 SN 66-004416 21:01 02/23/2002 COPY NUMBER 1 OF 2 SUB NAME=TEST, SQAP-RFI. SUB DOB =02/23/30 SUB SEX =MALE WEIGHT =001 OFFICER =WILL, W.C OFFICER BADGE=0000974 N.C.I.C NO.=AZ0071500 TEST BRAC VALUE TIME AIR BLANK .000 21:00 SUBJECT TEST REFUSED 21:01 SUBJECT REFUSED TO CONTINUE. OPERATOR: ADDITIONAL INFORMATION: RADIO DID NOT INTERFERE

GOODYEAR POLICE DEFT.

VERSION E 773.23 TIME 21:02

INVALID TEST

SUB NAME=TEST, SDAP-RFI,
SUB DOB =02/23/30
SUB SEX =MALE WEIGHT =001
OFFICER =WILL, W, C
OFFICER BADGE=0000974
N.C.I.C NO.=AZ0071500

INHIBITED - MH !	
OPERATOR:	
ADDITIONAL INFORMATION:	

GOODYEAR POLICE DEPT. INTOXILYZER - ALCOHOL ANALYZER AZ MODEL 5000 SN 65-004416 02/23/2002 21:04 COPY NUMBER 1 OF 2 SUB NAME=TEST, SQAP-MOA, SUB DOB =02/23/30 SUB SEX =MALE WEIGHT =001 OFFICER =WILL, W, C OFFICER BADGE=0000974 N.C.I.C NO.=AZ0071500 TEST BRAC VALUE TIME AIR BLANK .000 21:03 INVALID SAMPLE .MOA 21:04 AIR BLANK .000 21:04 BEGIN NEW DEPRIVATION PERIOD OPERATOR: ADDITIONAL INFORMATION:

GOODYEAR POLICE DEPT. INTOXILYZER - ALCOHOL ANALYZER AZ MODEL 5000 SN 66-004416 02/23/2002 21:08 COPY NUMBER 1 OF 2 SUB NAME=TEST.SQAP-DS. SUB DOB =02/23/30 SUB SEX =MALE WEIGHT =001 OFFICER =WILL,W,C OFFICER BADGE=0000974 N.C.I.C NO.=AZ0071500 TEST BRAC VALUE TIME AIR BLANK .000 21:05 *SUBJECT TEST .089 21:08 AIR BLANK .000 21:08 * DEFICIENT SAMPLE - VALUE PRINTED WAS HIGHEST OBTAINED. OPERATOR: ADDITIONAL INFORMATION:

EXHIBIT Q THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R9-14-404(A)

ARIZONA DEPARTMENT OF HEALTH SERVICES

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 5000*

AGENC	Y GOODYEAR PD QA SPECIALIST WILL
INTOXI DATE	LYZER SERIAL # 66-0044/6 LOCATION 6PD (Print Name) 2-23 2002 TIME 2/09
W	Display reads "READY TO START" or "PUSH BUTTON TO START TEST."
W U-	DSTIC TESTS DVM Test check. Setting should be between .200 and .600. Mode selection switch S2 on, S1 and S3 off or keyboard menu selection "H". Reading is
W W W	Alcohol-free subject Test result 0. AC Error recognition logic system functioning Invalid test printed Proper sample recognition system Invalid sample printed Deficient sample printed Completeness of sample purge with collection tube ** Calibration standard 0. ACResults: 0. O
COMME	ENTS:
 SIGNAT	TURE
0.	Alcohol concentration standard collection for subsequent analysis.**
	OR WITHOUT VAPOR RECIRCULATION AND WITH OR WITHOUT KEYBOARD STEP IS ONLY REQUIRED IF THIS DEVICE IS BEING USED FOR SAMPLE CAPTURE

DHS/DSLS/Form C117 (Rev. 7-93)

GOODYEAR POLICE DEPT. INTOXILYZER - ALCOHOL ANALYZER AZ MODEL 5000 SN 66-004416 02/23/2002 21:10 COPY MUMBER 1 OF 2 OFFICER BADGE=0000974 N.C.I.C NO.=AZ0071500 TEST BRAC VALUE
AIR BLANK .000
CAL. CHECK .102 TIME 21:09 .102 .000 21:09 AIR BLANK 21:10 OPERATOR: ADDITIONAL INFORMATION: