EXHIBIT P

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R9-14-404(A)

ARIZONA DEPARTMENT OF HEALTH SERVICES

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 5000 *

STANDARD CALIBRATION CHECK PROCEDURE

| Agency GO Intoxilyzer Se QA Specialis | | Date Location (Print Name) | 7-12-2005 GOODYEAN PD m #981 | |
|---|---|--|---|----------------|
| 1. 2. 3. 4. 5. 6. 7. 8. 9. 10. 11. 12. | Pour a standard alcohol solution of simulator. Insure that a tight seal if Turn on the simulator and allow the Set Intoxilyzer mode selection in the selecting "C" on keyboard menu. Attach simulator to the simulator er Intoxilyzer 5000 display reads "REA Push Start Test button or press ent Insert card in response to display. Air blank completed. Calibration check completed. Test Air blank completed. When display reads Test Complete Return mode selection switch # 9 to enter on keyboard. | has been made. Stander temperature to reach the ACA mode by switch that the ACA mode by switch that the ACA mode of the Interval of the Interv | dard value: 0./00 A 34° C +/- 0.2° C. ning mode selection swi oxilyzer. USH BUTTON". | itch # 9 on or |
| * WITH OR WITHOUT VAPOR RECIRCULATION AND WITH OR WITHOUT KEYBOARD | | | | |
| DHS/DSLS/Form C116 (Rev. 7-93) | | | | |

BOTTLE# 00220 LOT # 200403D

GOODYEAR PD-JUSTICE FACILITY SOUTH STATION #2 INTOXILYZER - ALCOHOL ANALYZER AZ MODEL 5000 SN 66-004416 10:36 07/12/2005 COPY NUMBER 1 OF 2 OFFICER BADGE=0000981 N.C.I.C NO.=AZ0071500 BRAC VALUE TIME TEST 10:35 AIR BLANK .000 . 099 10:36 CAL. CHECK 10:36 AIR BLANK .000 OPERATOR: ADDITIONAL INFORMATION: