EXHIBIT G-2 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SP	EC	HALIST WILL AGENCY GOODER PD
DATE		4/23/2009 TIME 1347
INTOX	ΚIL	YZER SERIAL # 80 - 1858 LOCATION GPD
(N	1.	Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solutionAC
		Pour a standard alcohol concentration solutionAC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}C \pm 0.2^{\circ}C$
U	2.	Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
W	3.	Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
W	4.	Air blank completed.
(W)	5.	Calibration check completed. Test results 0. () AC.
$(\mathcal{N})_{\perp}$		Air blank completed.
(W)	7.	Remove printed record. Attach the record to the completed checklist.
SIGNA	TU	JRE

DPS Form Exh G-2 (Rev 05-01)

INTOXILYZER 8000

Location: GOODYEAR POLICE DEPT

Serial Number: 80-001858

04/23/2009

13:47:25

Standard Lot#: 808401G

Last Changed By: W. WILL #974

75 PM 395 NO SEE NO SEE NO SEE NO DESCRIPTION OF THE SEE NO SEE N

QAS: W. WILL #974

GOODYEAR PD

Test		g/210L	Time		
The sale will will see the see that the see th					
Air	Blank	0.000	13:47:53		
Cal	Check	0.101	13:48:11		
Air	Blank	0.000	13:48:41		

Operator's Signature