EXHIBIT G-2 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GUILBAUG 1/41 AGENCY GOODS FAR POJCE
DATE 1/28/20/1 TIME 164/
INTOXILYZER SERIAL# 10-003/2 LOCATION 10701 SESTRELLA PKU
1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution AC.
Pour a standard alcohol concentration solutionAC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
 Intoxilyzer 8000 display reads "PUSH BUTTON TO START" Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed. (A) 5. Calibration check completed. Test results 0. AC. (B) 6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.
SIGNATURE // / /
DPS Form Exh G-2 (Rev 05-01)

PS Form Exh G-2 (Rev 05-01)

INTOXILYZER 8000

Location: 10701 S ESTRELLA Serial Number: 80-000312 Core Version: 8105.48

11/28/2011

16:41:15

------Standard Lot#: 06011100A1

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Test	g/210L	Time
Air Blank	0,000	16:41:47
0.100 Cal Check	(0.102)	16:42:08
Air Blank	0.000	16:42:37

Preventative Maintenance Performed -- Timer Reset