EXHIBIT G-2 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST M. GUENSAULT 1/44 AGENCY GOOD YEAR PY
DATE 4/11/13 TIME 15/8
INTOXILYZER SERIAL # 80-00/858 LOCATION 1070/ S ESTRELLA PKW
1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution AC. OR
Pour a standard alcohol concentration solutionAC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START" 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER. 4. Air blank completed. 5. Calibration check completed. Test results 0AC. 6. Air blank completed. 7. Remove printed record. Attach the record to the completed checklist.

DPS Form Exh G-2 (Rev 05-01)

INTOXILYZER 8000

Location: 10701 S ESTRELLA Serial Number: 80-001858 Core Version: 8105.48

04/11/2013

15:18:31

Standard Lot#: 13712100A2

Last Changed By: M. GUILBAULT #1144

QAS: M. GUILBAULT #1144

GOODYEAR PD

Operator: M. GUILBAULT #1144

GOODYEAR PD

Test g/210L Time

Air Blank 0.000
0.100 Cal Check 0.100
Air Blank 0.000

15:19:07 15:19:28 15:19:57



Preventative Maintenance Performed -- Timer Reset