EXHIBIT G-2 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST W.C. Will #974	AGENCY Goodyear Police Department
DATE (2-29-2008	TIME 08'06
INTOXILYZER SERIAL # 80-001858	LOCATION Goodyear Police Department
() 1. Ensure that gas tank is attached to instrument and	contains a standard alcohol concentration solution / Do AC.
simulator. Ensure that a tight seal has been made. $/$ 0.2°C	AC, into a clean dry simulator and assemble the Turn on the simulator and allow temperature to reach 34°C \pm
2. Intoxilyzer 8000 display reads "PUSH BUTTON"	TO START"
3. Go to the "Control Testing Menu". Select "D" for made press ENTER.	dry control test or "W" for wet control test. After selection is
() 4. Air blank completed.	
(1) 5. Calibration check completed. Test results 0.	ON AC.
(\checkmark) 6. Air blank completed.	
7. Remove printed record. Attach the record to the co	ompleted checklist.
SIGNATURE MIC CHIEF	

DPS Form Exh G-2 (Rev 05-01)

INTOXILYZER 8000

Location: GOODYEAR POLICE DEPT

Serial Number: 80-001858

12/29/2008

08:06:51

------Standard Lot#: 808401G

Last Changed By: W. WILL #974

QAS: W. WILL #974

GOODYEAR PD

Test	g/210L	Time
Air Blank	0.000	08:07:19
Cal Check	0.100	08:07:38
Air Blank	0.000	08:08:07

Operator's Signature